

#P7224 shown



#P7224B shown







#P7225B shown



#P7223RK shown



#P3225D shown



#K24TB shown



#K25TB shown

## **Traditional Schedule 40 Bath Waste**

- Schedule 40 PVC or ABS construction.
- Single hole faceplate mounting hardware included.
- Snap-on & threaded test kit.Foam rubber overflow gasket.

| Product No.  | Description                                                                                                   | Ctn. Qty. |
|--------------|---------------------------------------------------------------------------------------------------------------|-----------|
| Full Kits    |                                                                                                               |           |
| P7224        | Traditional PVC Full Kit, Touch Toe Stopper w/ Test Kit & Chrome Finish                                       | 10 🖫      |
| P7225        | Traditional PVC Full Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish                                        | 10 🖫      |
| A7224        | Traditional ABS Full Kit, Touch Toe Stopper w/ Test Kit & Chrome Finish                                       | 10 🖫      |
| A7225        | Traditional ABS Full Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish                                        | 10 🖫      |
| Half Kits    |                                                                                                               |           |
| P7224B       | Traditional PVC Half Kit, Touch Toe Stopper w/ Test Kit & Chrome Finish                                       | 20 🐯      |
| P7444B       | Traditional PVC Half Kit, Touch Toe Stopper (Tap-Tap) w/ Test Kit & Chrome Finish                             | 20 🖫      |
| P7225B       | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish                                        | 20 🐯      |
| P7225BAB     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Antique Bronze Finish                                | 20 🐯      |
| P7225BBN     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Brushed Nickel Finish                                | 20 🐯      |
| P7225BRB     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Oil Rubbed Bronze Bronze Finish                      | 20 🐯      |
| P7225BSN     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & UltraShine® Satin Nickel Finish                      | 20 🐯      |
| P7225BWH     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & White Finish                                         | 20 🐯      |
| P7225BZ      | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish, Zinc Drain Spud                       | 20 🖫      |
| P7225BC      | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish & Condensate Elbow                     | 20 🖫      |
| P7225BCZ     | Traditional PVC Half Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish & Condensate Elbow, Zinc Drain Spud    | 20        |
| P9225BBG     | Traditional PVC Half Kit, Uni-Lift Stopper w/o Test Kit & Chrome Finish, Zinc Drain Spud, 2<br>Hole Faceplate | 25        |
| A7224B       | Traditional ABS Half Kit, Touch Toe Stopper w/ Test Kit & Chrome Finish                                       | 20 🖫      |
| A7225B       | Traditional ABS Half Kit, Uni-Lift Stopper w/ Test Kit & Chrome Finish                                        | 20 🐯      |
| Rough Kits   |                                                                                                               |           |
| P7223RK      | Traditional PVC Rough Kit, Chrome Finish                                                                      | 30 🐯      |
| P7223CRK     | Traditional PVC Rough Kit, Chrome Finish w/ Condensate Elbow                                                  | 30 🐯      |
| P7220BF      | Traditional PVC Rough Kit, Cable Drive w/ Chrome Finish                                                       | 20 🐯      |
| A7223RK      | Traditional ABS Rough Kit, Chrome Finish                                                                      | 30 🖫      |
| Quarter Kits |                                                                                                               |           |
| P3225D       | Traditional PVC Quarter Kit, Uni-Lift Stopper w/ Chrome Finish, Direct Drain                                  | 20 🐯      |
| Trim Kits    |                                                                                                               |           |
| K24TB        | Traditional Trim Kit, Touch Toe Stopper w/ Chrome Finish*                                                     | 10 🐯      |
| K74TBN       | Traditional Trim Kit, Touch Toe Stopper w/ Brushed Nickel Finish                                              | 10 🖫      |
| K74TSN       | Traditional Trim Kit, Touch Toe Stopper w/ UltraShine® Satin Nickel Finish                                    | 10 🖫      |
| K25TB        | Traditional Trim Kit, Uni-Lift Stopper w/ Chrome Finish*                                                      | 10 🖫      |
| K75TRB       | Traditional Trim Kit, Unilift Stopper w/ Oil Rubbed Bronze Finish                                             | 10 🖫      |
| K75TSN       | Traditional Trim Kit, Uni-Lift Stopper w/ UltraShine® Satin Nickel Finish                                     | 10 🖫      |
| K25TBZ       | Traditional Trim Kit, Uni-Lift Stopper w/ Chrome Finish, Zinc Drain Unit Included                             | 10        |

\*Chrome finish trim kits do not include spud