









MODEL NO.	DESCRIPTION	MODEL NO.	DESCRIPTION
<p>9000.250 Large Wood Cutting Board 17-3/4 x 15-1/2 x 1-7/8"</p>  <p>Large cutting board designed for use on sink or countertop. Board has a cutout to pass waste through or for a specially designed colander (available separately). Four rubber feet keep the board secure while cutting on sink, or these feet lift board over rim of sink when using on countertop so waste can be passed directly into disposer. *Designed for use on: 7183, 7196 large bowl, 7179 large bowl, 7145 both bowls, 7172, 7163 and 7000 sinks.</p>	<p>8105.100 Deep Web Mounted Colander 5-1/4 x 5-3/4 x 1-3/8"</p>  <p>Molded plastic colander mounts on divider between double bowl sinks. Hang this colander on web to hold and rinse vegetables or to rinse and dry utensils. Adapter included for attachment when not using web cover. Dishwasher safe, top shelf. Designed for use on: 7183, 7196, 7179, 7145, 7163 and 7000 sinks.</p>		
<p>9000.185 Small Wood Cutting Board 15-1/2 x 13 x 1-7/8"</p>  <p>Board has a cutout to pass waste through or for a specially designed colander (available separately). Four rubber feet keep the board secure while cutting on sink, or these feet lift board over rim of sink when using on countertop so waste can be passed directly into disposer. Designed for use on: 7185 series island sink.</p>	<p>8104.100 Shallow Web Mounted Colander 5-1/4 x 5-3/4 x 1-3/8"</p>  <p>Molded plastic colander mounts on divider between double bowl sinks. This handy colander mounts right on web to hold and rinse garnish or store soap or scouring pads. Adapter included for attachment when not using web cover. Dishwasher safe, top shelf. Designed for use on: 7183, 7196, 7179, 7145, 7163 (not ADA model), and 7000 sinks.</p>		
<p>8102.100 Colander 10-5/8 x 3-5/8 x 1-1/2"</p>  <p>Molded plastic colander fits in cutout of 9000.250 or 9000.185 cutting board. Use to hold and rinse garnish cut on board. Dishwasher safe, top shelf. Designed for use in: 9000.250 or 9000.185 cutting board.</p>	<p>8106.100 Web Cover 17 x 4-1/8 x 1-5/8"</p>  <p>Molded rubber, this cover is designed to fit over divider between double bowl sinks. This will provide stable base for scrubbing pots and pans while keeping porcelain free from scratches. Designed for use with: 7183, 7179, 7145, 7196, and 7163 sinks.</p>		
<p>8103.100 Large Colander 17 x 7-1/4 x 2-1/2"</p>  <p>Molded plastic colander fits in specially designed rim of kitchen sink. Slides easily across sink for catching vegetables, rinsing fruit or straining pasta. Dishwasher safe, top shelf. Designed for use on: 7183, 7196, 7179, 7145, 7172, 7163 and 7000 sinks.</p>	<p>7346.100 Rubbermaid® Utility Basket 14-1/4 x 12-1/2 x 5-1/2"</p>  <p>Vinyl coated steel. This utility basket can be used for washing pots and dishes, defrosting meats, or to rinse fruits and vegetables. Small posts in bottom of basket hold glasses securely while drying. Use with: 7183 and 7196 large bowl, 7145 either bowl, 7163, 7173, 7103, 7172 and 7000 sinks.</p>		

Silhouette™ Americast Kitchen Sink Accessories



MODEL NO. LIST PRICE DESCRIPTION

Bottom Sink Racks

Bottom Sink Racks conform to the bottom bowl dimensions of Silhouette sinks keeping the porcelain free from scratching. Outlets in sink racks align with Silhouette's drain outlets allowing for waste and water to pass through. Sink racks available in White Heat (208) and Bone (021).



⚡ 7406.100 for use with

7145/7163 right hand bowl
7183 right hand bowl





⚡ 7405.100 for use with

7145/7163 left hand bowl
7183 left hand bowl



⚡ 7404.100 for use with

7172 Single bowl



⚡ 7407.100 for use with

7179 left hand bowl
7196 left hand bowl

