



| b<br>mm | f<br>mm | f <sub>1</sub><br>mm | l <sub>1</sub><br>mm | Module size | Type        | Grooving module     | Toolholder         |
|---------|---------|----------------------|----------------------|-------------|-------------|---------------------|--------------------|
|         |         |                      |                      |             |             |                     |                    |
| 16      |         | 18.9                 | 98                   | E16         | GX 09-1 ... | MSS-E16R/L07-GX09-1 | MSS-E16R/L00-1616G |
| 16      |         | 18.6                 | 98                   | E16         | GX 09-2 ... | MSS-E16R/L07-GX09-2 | MSS-E16R/L00-1616G |
| 20      |         | 23.9                 | 123                  | E20         | GX 16-1 ... | MSS-E20R/L12-GX16-1 | MSS-E20R/L00-2020J |
| 25      |         | 30.8                 | 153                  | E25         |             | MSS-E25R/L12-GX16-1 | MSS-E25R/L00-2525L |
| 20      |         | 23.6                 | 123                  | E20         | GX 16-2 ... | MSS-E20R/L12-GX16-2 | MSS-E20R/L00-2020J |
| 25      |         | 30.4                 | 153                  | E25         |             | MSS-E25R/L12-GX16-2 | MSS-E25R/L00-2525L |
| 25      |         | 30.4                 | 173                  | E32         |             | MSS-E32R/L12-GX16-2 | MSS-E32R/L00-3225N |
| 20      |         | 23.1                 | 123                  | E20         | GX 16-3 ... | MSS-E20R/L12-GX16-3 | MSS-E20R/L00-2020J |
| 25      |         | 29.9                 | 153                  | E25         |             | MSS-E25R/L12-GX16-3 | MSS-E25R/L00-2525L |
| 25      |         | 29.9                 | 173                  | E32         |             | MSS-E32R/L12-GX16-3 | MSS-E32R/L00-3225N |
| 25      |         | 29.3                 | 153                  | E25         | GX 16-4 ... | MSS-E25R/L12-GX16-4 | MSS-E25R/L00-2525L |
| 25      |         | 29.3                 | 173                  | E32         |             | MSS-E32R/L12-GX16-4 | MSS-E32R/L00-3225N |
| 20      |         | 23.6                 | 132                  | E20         | GX 24-2 ... | MSS-E20R/L21-GX24-2 | MSS-E20R/L00-2020J |
| 25      |         | 30.4                 | 162                  | E25         |             | MSS-E25R/L21-GX24-2 | MSS-E25R/L00-2525L |
| 25      |         | 29.9                 | 162                  | E25         | GX 24-3 ... | MSS-E25R/L21-GX24-3 | MSS-E25R/L00-2525L |
| 25      |         | 29.9                 | 182                  | E32         |             | MSS-E32R/L21-GX24-3 | MSS-E32R/L00-3225N |
| 25      |         | 29.3                 | 162                  | E25         | GX 24-4 ... | MSS-E25R/L21-GX24-4 | MSS-E25R/L00-2525L |
| 25      |         | 29.3                 | 182                  | E32         |             | MSS-E32R/L21-GX24-4 | MSS-E32R/L00-3225N |
| 25      |         | 28.5                 | 162                  | E25         | GX 24-5 ... | MSS-E25R/L21-GX24-5 | MSS-E25R/L00-2525L |
| 25      |         | 28.9                 | 194                  | E32         | LX - ...    | MSS-E32N32-LX       | MSS-E32R/L00-3225N |
| 25      |         | 28.9                 | 207                  | E32         |             | MSS-E32N45-LX       | MSS-E32R/L00-3225N |

Accessories

|  | Module size       | E32              |
|--|-------------------|------------------|
|  | Handle key, small | FS1048 (Torx 20) |