



Models/Modelos/Modèles

777-LHP-DST

Series/Series/Seria



RP70933-1.2
Aerator & Wrench
Aerador y Llave
Aérateur et Clé

RP91902
Valve Assembly
Ensamble de la válvula
Soupape

RP91903▲
Bonnet Nut & Cap
Tuerca tapa y Tapa
Écrou-chapeau et
capuchon

RP100359▲
Gasket (1 Hole Only)
Empaque (1 agujero solo)
Joint (1 trou seulement)


RP47029
Mounting Bracket
Abrazadera
Support

RP47030
Nut & Wrench Assembly
Ensamble de Tuerca y Llave
Écrou et clé


RP51243
Gaskets
Empaques
Joints

RP50952
Plastic Sleeves
Mangas Plásticas
Manchons en plastique

H550▲
Handle Assembly
El ensamble de la manija.
Manette



H551▲
Handle Assembly
El ensamble de la manija.
Manette



▲ Specify Finish / Especificue el Acabado / Précisez le Fini