Hansgrohe Internet Dealer www.NeedPlumbingSupplies.com 800-728-8890

# **Installation Instructions / Warranty**

## QUATTRO FOUR WAY DIVERTER **Trim sets**



Starck 10933XX1



Montreux 16830XX1



Carlton 17933XX1



Carlton 17935XX1



**Phoenix** 



**Phoenix** 



Steel



17944XX1

**Terrano** 



37933XX1



38933XX1





37930XX1



Rough-in Ref. No.: 13932181


**Citterio** 39925XX1


Mondial/ Metris/ Elegance/ **Sportive** 

15935XX1

hansgrohe


AXOR PHÂRO






## Sleeve and escutcheon assembly


- 1. Remove the cover
- Seal around the rough-in with waterproof bathroom sealant



 Push the guide ring into the body of the roughin, only necessary for Starck10933XX1, Montreux 16830XX1, Phoenix 17944XX1/17945XX1, Terrano 37930XX1/37933XX1, Uno 38933XX1 and Citterio 39920XX1 / 39925XX1.




4. Install the trim sleeve and the escutcheon.



## Handle assembly


Starck 10933XX1 Montreux 16830XX1 Terrano 37930XX1 / 37933XX1

- 1. Push the handle onto the shaft.
- 2. Fix the screw.
- 3. Cover the hole by the plastic cap.




Carlton 17933XX1 / 17935XX1 Phoenix 17944XX1 / 17945XX1

- 1. Push the handle onto the shaft.
- 2. Fix the screw.
- 3. only Phoenix cross handle: Cover the hole by the plastic cap.



Steel 35933801 Allegroh 36933XX1 Uno 38933XX1 Mondial / Metris / Elegance / Sportive 15935XX1

- 1. Lock the screw by hand only three turns.
- 2. Snap on the handle.
- 3. Fix the screw.
- 4. Cover the hole by the plastic cap.




## Citterio 39920XX1 / 39925XX1

- 1. Install the handle fixation and lock the screw.
- 2. Snap on the handle.
- 3. Fix the hollow set screw with a hex wrench 2 mm.

spare paris				
1	escutcheon	Montreux		98669XX1
	escutcheon	Starck/Carlton/Phoenix/	/Steel/Allegroh/Terrano/Citterio/Uno/	
		Mondial/Metris/Elegano	ce/Sportive	13936XX0
2	handle	Starck		10993XX1
2.1	screw-cover	Starck		96540XX1
3	sleeve			
		Mondial/Metris/Elegand	ce/Sportive	96242XXX
	sleeve	Steel		96242XXX
4	cross handle	Carlton		1 <i>7</i> 993XX1
5	lever handle	Carlton		17298XX1
6	handle	Steel		35993801
6.1	screw-cover Steel/Allegroh/Uno/Mondial/Metris/			
_		Elegance/Sportive/Phoenix cross handle		96541001
7	handle	Allegroh		
•		Mondial/Metris/Elegance/Sportive		36993XX1
8	cross handle	Terrano		37995XX1
8.1	screw-cover	Terrano		96542XX0
9	lever handle	Terrano		37993XX1
9.1	screw-cover	Terrano		96543XX0
10	handle	Uno		38993XX1
11	lever handle	Phoenix		96632XX1
12	cross handle	Phoenix		96792XX1
13	lever handle	Citterio		39993XX1
14	cross handle	Citterio		39995XX1
15	cross handle	Montreux		16593XX0
15.	l screw-cover	Montreux		97987000
XX = Color code:		00 chrome	<b>-</b>	00/0000
		09 chrome/gold	Extension Set 1 1/2"	92630000
		42 platin	(If needed, please order separately)	
		80 steel		
		81 satinox		

82 brushed nickel 83 polished nickel 88 satin chrome



## **Cleaning Recommendation for Hansgrohe Products**

Modern faucetry and shower products utilize a combination of materials to comply with the needs of the market with regard to design and functionality.

To avoid damage, it is necessary to use some caution when cleaning. Damage caused by improper treatment is not covered under the Hansgrohe warranty.

## **Cleaning Materials for Faucets and Showers**

- To remove lime scale, use only products made specifically for that purpose. Always follow the manufacturer's instructions when using.
- Do not use cleaners that contain hydrochloric, formic, acetic, or phosphoric acids, as these will cause considerable damage to finishes and to plastic components.
- Never mix cleaning materials.
- Never use cleaners containing abrasives. Do not use abrasive cleaning cloths, pads, or sponges.

## **Cleaning Procedures**

- Clean your faucets and shower products as and when required. Regular cleaning will prevent scale buildup and water spotting.
- Follow the label instructions. Do not allow any cleaner to remain on the product for longer than necessary.
- When using spray cleaners, spray first onto a sponge or cloth do not spray directly onto the product.
- After cleaning, rinse thoroughly with clear water to remove any cleaner residue.

## **Important**

- Soap and shampoo residue can also cause damage to the product. Rinse well with clean water after use.
- · If the surface is already damaged, harsh cleaning materials will cause further damage.

## **Limited Lifetime Consumer Warranty**

This product has been manufactured and tested to the highest quality standards by Hansgrohe, Inc. ("Hansgrohe"). This warranty is limited to Hansgrohe products which are purchased by a consumer in the United States after March 1, 1996, and installed in either the United States or Canada.

#### WHO IS COVERED BY THE WARRANTY

This warranty extends to the original consumer purchaser only.

## WHAT IS COVERED BY THE WARRANTY

This warranty covers only your Hansgrohe manufactured product. Hansgrohe warrants this product against defects in material or workmanship as follows: Hansgrohe will repair at no charge for parts only or, at its option, replace any product or part of the product which proves defective because of improper workmanship and/or material, under normal installation, use, service and maintenance. If Hansgrohe is unable to provide a replacement and repair is not practical or cannot be timely made, Hansgrohe may elect to refund the purchase price in exchange for the return of the product.

#### **LENGTH OF WARRANTY**

Replacement or repaired parts of products will be covered for the term of this warranty as stated in the following two sentences. If you are a consumer who purchased the product for use primarily for personal, family, or household purposes, this warranty extends for as long as you own the product and the home in which the product is installed. If you purchased the product for use primarily for any other purpose, including, without limitation, a commercial purpose, this warranty extends only (i) for 1 year, with respect to Interaktiv and Retroaktiv products, and (ii) for 5 years, with respect to AXOR, ShowerPower and Pharo products.

## THIS WARRANTY DOES NOT COVER, AND HANSGROHE WILL NOT PAY FOR:

- A. Conditions, malfunctions or damage not resulting from defects in material or workmanship.
- B. Conditions, malfunctions or damage resulting from (1) improper installation, improper maintenance, misuse, abuse, negligence, accident or alteration, or (2) the use of abrasive or caustic cleaning agents or "no rinse" cleaning products, or the use of the product in any manner contrary to the product instructions.
- C. Labor or other expenses for the disconnection or return of the product for warranty service, or for installation or reinstallation of the product.
- D. Accessories or related products not manufactured by Hansgrohe.

#### TO OBTAIN WARRANTY SERVICE

Contact your Hansgrohe retailer, or write to Technical Service at:

Hansgrohe Inc.

1492 Bluegrass Lakes Parkway

Alpharetta GA 30004

Or, call Hansgrohe toll-free at (800) 334-0455.

In requesting warranty service, you will need to provide

- 1. The sales receipt or other evidence of the date and place of purchase.
- 2. A description of the problem.
- Delivery of the product or the defective part, postage prepaid and carefully packed and insured, to Hansgrohe Inc. 1492 Bluegrass Lakes Parkway, Alpharetta, Georgia 30004, Attention: Technical Service, if required by Hansgrohe.

When warranty service is completed, any repaired or replacement product or part will be returned to you postage prepaid.

#### **EXCLUSIONS AND LIMITATIONS**

REPAIR OR REPLACEMENT (OR, IN LIMITED CIRCUMSTANCES, REFUND OF THE PURCHASE PRICE) AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. HANSGROHE NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO CREATE FOR IT ANY OBLIGATION OR LIABILITY IN CONNECTION WITH THIS PRODUCT.

HANSGROHE SHALL NOT BE LIABLE TO PURCHASER OR ANY PERSON FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF BREACH OF THIS WARRANTY OR ANY IMPLIED WARRANTY (INCLUDING MERCHANTABILITY).

Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may have other rights which vary from State to State.

You may be required by law to give us a reasonable opportunity to correct or cure any failure to comply before you can bring any action in court against us under the Magnuson-Moss Warranty Act.

#### PRODUCT INSTRUCTIONS AND QUESTIONS

Upon purchase or prior to installation, please carefully inspect your Hansgrohe product for any damage or visible defect. Prior to installing, always carefully study the enclosed instructions on the proper installation and the care and maintenance of the product. If you have questions at any time about the use, installation, or performance of your Hansgrohe product, or this warranty, please call or write to us at the toll-free number and address printed above.