


■ Order by Part Number


Stopper - Polished Stainless  
1011



Removable Splash Guard  
205497



Sink Flange - Polished Stainless  
1017



### Mounting Assembly Kit - 1824

Fiber Gasket

Backup Flange


Screws (x3)

Mounting Ring

Snap Ring

Cushion Mount

Lower Mounting Ring




### Drain Elbow Kit - 1026

Rubber Gasket

Screws

Drain Elbow




Replacement Power Cord Kit  
1024



### Garbage Disposals

MODEL GX50c

### Other Available Accessories



#### Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

#### Air Switch Base Unit

Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Mediterranean Bronze	AS-4201-BRB
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS

#### Optional:

Dishwasher Connector Kit  
1023



Unjamming Wrench  
1037

