

Hose Barb Fittings

Brass Fittings

er.		Part No.	I.D. x O.D.
<u>ဗ</u>		HS-B3	1/4" x 1/2"
Hose Splicer		HS-B5	1/4" x ⁹ /16"
		HS-B7	1/4" x 5/8"
SQ.	(A)	HS-D7	3/8" x 5/8"
Ĭ	0 0	HS-D9	³ /8" X ¹¹ / ₁₆ "
		HS-D11	³ /8" x ³ /4"
		HS-D13	³ /8" X ¹³ /16"

Stem		Part No.	MPT x I.D. STEM	
se { ivel		M7S	½" x ½"	
Ho Sw		M13S	³ /8" x ³ /8"	
Male Hose Swive		M17S	½" x ½"	
	Requires Hose Clamp (See page 200 for typical hose clamps)			

-On Fitting		Part No.	Male NPT x I.D.		
		PM7S	1/4" x 1/4"		
Push- Swivel F		PM13S	³ / ₈ " x ³ / ₈ "		
Sw		PM17S	½" x ½"		
	Hose clamps not required when used with "Push On" hose. See page 369.				

	Standard Hose Barb	Part No.	Brand	Hose I.D.	
arb		BHS81	F	³ / ₁₆ "	
er B		BHS82	F	1/4"	
Splicer Hose E		HS-2-2	В	/4	
		BHS83	F	⁵ / ₁₆ "	
Hose ndard		BHS84	F	3/8"	
		HS-3-3	В	/8	
Sta		BHS85	F	1/2"	
		HS-4-4	В	/2	
	Requires Hose Clamp (See page 200 for typical hose clamps)				

Hose Splicer Push-Lock		Part No.	Brand	Hose I.D.
		PHS82	F	1/4"
		POS-2-2	В	/4
		PHS84	F	3/8"
		POS-3-3	В	78
		PHS85	F	1/2"
		POS-4-4	В	/2
		POS-6-6	В	3/4"
	Hose clamps not required when used with "Push On" hose. See page 369.			

		Part No.	Brand	Hose I.D.	NPT Thread Size
		HBF-1-1	В	1/8"	1/8-27
		HBF-1-2	В		1/4-18
		HBF-25-1	D	³ / ₁₆ "	1/8-27
		HBF-25-2	B		1/4-18
		F33	F	1/4"	¹ / ₈ -27
ark		HBF-2-1	В		/8-21
ë B		F36	F		1/4-18
08		HBF-2-2	В		/4-10
늘		HBF-5-2	В	5/16"	1/4-18
rea		HBF-3-1	В	3/8"	1/8-27
, Th		F38	F		1/4-18
ipe		HBF-3-2	В		/4-10
Female Pipe Thread Hose Barb		F40	F		³/ ₈ -18
na		HBF-3-3	В		
-e		HBF-3-4	D		1/2-14
		HBF-4-2	B		1/4-18
		F41	F	1/2"	³/ ₈ -18
		HBF-4-3	В		
		F42	F		1/2-14
		HBF-4-4	В		/2 17
		HBF-6-6	В	3/4"	³ / ₄ -14
	Requires Hose Clamp ((See page 200 for	r typical	hose clamps)	

Brand - Designates =Foster or B=Breco Part

– 358 – www.zsi-foster.com